

**OPERATION INSTRUCTIONS:-**

1. Insert 1 or 2pcs of 9Vrechargeable Ni-Cd / Ni-MH battery into the battery compartment.
2. Make correct contact for polarity (+ and -); according to the sign in the battery compartment.
3. Plug the charger into a correct household electric outlet. The LED will light up instantly to indicate the proper charging.
4. Observe the charging time. Unplug the charger when the charging is finished.

**CHARGING TIME:**

<u>Capacity of battery</u>	<u>By manual</u>
9V NiCd 100mAh	9 hours
9V NiCd 120mAh	11 hours
9V NiMH 120mAh	11 hours
9V NiMH 150mAh	13 hours
9V NiMH 170mAh	15 hours

**CAUTION:**

1. Before charging, read instruction.
2. This charger is intended for use with Nickel-Cadmium and Nickel-metal-hydride rechargeable batteries only. Attempting to charge other types of batteries may cause personal injury and damage to the charger.
3. Recharge only one type of battery (Ni-Cd or Ni-MH) at each time.
4. Do not charge longer than time specified. Overcharging may cause damage to the charger and battery.
5. Do not expose charger to rain or moisture. For indoor use only.
6. Remove from mains when not in use.
7. This charger is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.