

Instruction for model T-2833

OPERATING INSTRUCTIONS :-

1. Insert 2 or 4pcs of AA / AAA rechargeable Ni-Cd / Ni-MH battery into the battery compartment; battery must be charged in pairs.
2. Make correct contact for polarity (+ and -); according to the sign in the battery compartment.
3. When charging only 2 cells, place in the front panel of battery compartment.
4. For charging AAA battery, pull down the adjustable battery contact plate first and then insert the AAA batteries into the compartment. Now the AAA batteries will be hold firmly inside the compartment. The charger will adjust the suitable charging current for AAA size battery automatically.
5. Plug the charger into a correct household electric outlet. The LED will light up instantly to indicate the proper charging.
6. Observe the charging time. Unplug and re-plug the charger each time when you recharge the empty batteries.

CHARGING TIME

MIGNON - R6	BY MANUAL
AA - 600 mAh	5 hours
AA - 700 mAh	6 hours
AA - 800 mAh	7 hours
AA - 1000 -1200 mAh	8 - 10 hours
AA - 1300 -1500 mAh	10 - 12 hours
AA - 1600 -1800 mAh	12 - 14 hours
MICRO - R03	BY MANUAL
AAA - 240 mAh	5 hours
AAA - 320 mAh	7 hours
AAA - 500 - 600 mAh	10 - 12 hours
AAA - 650 - 750 mAh	12 - 14 hours

CAUTION:

1. Before charging, read instruction.
2. This charger is intended for use with Nickel-Cadmium and Nickel-metal-hydride rechargeable batteries only. Attempting to charge other types of batteries may cause personal injury and damage to the charger.
3. Recharge only one type of battery (Ni-Cd or Ni-MH) at each time.
4. Do not charge longer than time specified. Overcharging may cause damage to the charger and battery.
5. Do not expose charger to rain or moisture. For indoor use only.
6. Remove from the mains when not in use.
7. This power unit is intended to be correctly orientated in a vertical or floor mount position.